


Exploded View B82456 B82639



REPAIR PARTS LIST

Key No.	Part Description	No. Used	B82456	B82639
1	Motor	1	M15087	M14007
2	Socket Head Capscrew	4	U30-104ZP	U30-104ZP
3	Slinger	1	17351-0009	17351-0009
4	Bracket	1	M13784	M13784
5	Impeller Repair Kit (Includes Key Nos. 6-8 and 10-14)	1	B85604	B85604
6	Shaft Seal*	1	U9-6	U9-6
7	Spacer	1	121P1710	121P1710
8	O-Ring	2	111P2700	111P2700
9	Sleeve	1	251A4310	251A4310
10	Diffuser	4	101P4790	101P4790
11	Impeller	4	101P2070	101P2070
12	Washer, Flat	1	121P1760	121P1760
13	Washer, Toothed	5	M13975	M13975
14	Impeller Nut	1	U36-204SSW	U36-204SSW
15	Pump Body (Suction)	1	751S4800	751S4800
16	Washer	2	121P0810	121P0810
17	Pipe Plug	2	171P1180	171P1180
18	Capscrew	4	121P1690	121P1690
19	Recirculation Valve Complete (Includes O-Ring)	1	ZBR05820	ZBR05820

*To order shaft seal as a separate part, order Part No. U109-6A.